


STÛV 21 LINEAR GRILLE

INSTALLATION MANUAL

Keep these instructions for future reference



REQUIRED TOOLS AND MATERIAL



Impact drill



Level



Measuring tape



Knife with
retractable blade




Floor and wall
finishing




Metal framing

REQUIRED HARDWARE



No. 2
square bit



8mm
hex socket

and/or



8 mm
ratchet wrench



1" no. 8
wood screw



1/2" no. 8
metal screw



IMPORTANT

This document is an appendix to the **Stûv 21** installation manual. These instructions are complementary and must be carefully followed.

Look for this symbol in the **Stûv 21** installation manual to know when to refer to this appendix.




TABLE OF CONTENTS

1. DIMENSIONS



3

1.1	Dimensions and Part Numbers	4
1.2	Minimum Non-Combustible Materials	5
1.3	Recommended Installation	6
1.4	Option: Convection Air Intake Built Into a Wall	7

2. INSTALLATION



8

2.1	Preparing for the Installation	9
2.2	Installing the Framing	10
2.3	Adjustment Supports	11
2.4	Convection	12
2.5	Positioning the System	13
2.6	Finishing the Wall	14



CAUTION

Read the safety instructions in the Stûv 21 installation manual before using your fireplace.

Upon first uses, some smoke or odours may be produced.


Ventilate the room well.



1

DIMENSIONS


1.1	DIMENSIONS AND PART NUMBERS	4
1.2	MINIMUM NON-COMBUSTIBLE MATERIALS	5
1.3	RECOMMENDED INSTALLATION	6
1.4	OPTION: CONVECTION AIR INTAKE BUILT INTO THE WALL	7



1.1 DIMENSIONS AND PART NUMBERS



CONNECTION BOX



LEXICON

- ① Contour
- ② Connection box
- ③ Left adjustment support
- ④ Right adjustment support
- ⑤ M5 x 16 mm hex head screws
- ⑥ Connection flange


MODEL	CODE	A
21-85	1200200001	30 ⁹ / ₁₆ "
21-95	1200200002	35 ¹ / ₂ "
21-105	1200200003	39 ⁷ / ₁₆ "
21-125	1200200004	47 ⁵ / ₁₆ "

*This dimension indicates the distance between the top of the steel track to the opening of the linear grille, which will help guide the framing's installation.

PICTURE TYPE FRAME

CAUTION: PAINT IS FRAGILE

Upon receiving, make sure the frame is in good condition. Repackage until ready to install in the connection box contour.




ADJUSTMENT

The adjustment permits the installation of 1/2"- to 3"-thick wall finishing.

MODEL	CODE	C	L
21-85	1200100001	32 ⁷ / ₈ "	30 ⁷ / ₈ "
21-95	1200100002	36 ¹³ / ₁₆ "	34 ¹³ / ₁₆ "
21-105	1200100003	40 ¹¹ / ₁₆ "	38 ¹¹ / ₁₆ "
21-125	1200100004	48 ⁵ / ₈ "	46 ⁵ / ₈ "

The other parts provided are described in the Stûv 21 installation manual.

1.2 MINIMUM NON-COMBUSTIBLE MATERIALS



The connection box of the linear grille can reach high temperature went the fireplace is in operation. It is mandatory to respect a minimum of **4" clearance to combustibile materials below and on the sides**, and **12" above** the contour of the linear grille, up to the center of the chimney. Materials exposed to radiation must be resistant to high temperatures.


To avoid major damage, no combustibile material should be placed in the risk zone and in front of a hot air outlet. In addition, blocking it may cause the unit to overheat and, in some cases, lead to a fire. Be sure to follow the above recommendations to **avoid heat traps** or other major damage risks.

CAUTION


- See the Stûv 21 installation manual for any framework information not specified on this page.
- Do not place any items inside the linear grille.
- The ceiling must be a minimum distance of 12" from the top of the opening of the linear grille, which equals 9" with the top of the support track.
- It is important to know the thickness of the wall finishing and ensure that it is a non-combustible material before installing the grille.
- To install a convection built into the wall, call on a professional installer and follow the recommendations on the next page.

- cement board
- drywall

MODEL	F
21-85	32"
21-95	35 7/8"
21-105	39 7/8"
21-125	47 3/4"



1.3 RECOMMENDED INSTALLATION




! RECOMMENDATIONS

These instructions are not mandatory, but strongly recommended :

- Build an all-steel structure above the fireplace
- Leave a minimum distance of 12" from the top of the fireplace to facilitate the passage of the connection box and the pipes.
- Apply a single cement board panel, not several pieces.

These recommendations are additional. The minimums listed on the previous page must be respected.




1.4 OPTION: CONVECTION AIR INTAKE BUILT INTO A WALL




CAUTION

1. The convection air intake built into a wall can replace the provided grilles.
2. The convection air intake built into a wall can be separated into two intakes.
3. The cutouts under the fireplace must be knocked out. See the Stûv 21 installation manual.
4. The intake surface area and entire air circuit must be minimum **56 in²** otherwise the convection will be inadequate. See the table at the bottom of the page for the minimum dimensions.
5. To install a convection air intake built into the wall, the hearth must be at a height of minimum **12"** (or **16"** with the airtight box and the mandatory adjustable stand).
6. We recommend to install an airtight box in this type of installation.



MODEL	Width of the linear grille (L)	Minimum height (H)
21-85	30 7/8"	1 7/8"
21-95	34 13/16"	1 5/8"
21-105	42 11/16"	1 3/8"
21-125	46 5/8"	1 1/4"

SECTION VIEW



The convection's surface area must be calculated prior to installation and validated onsite. **The client and installer are responsible for validating that the construction permits sufficient convection air movement.**

*The sealing strip must protect the subfloor and prevent ash and hot embers from coming into contact with combustible materials. The strip must be installed under the cement board and under the non-combustible flooring.

All materials placed under the fireplace and its insulated shell must be **non-combustible** (metal framing, cement board, etc.)

2

INSTALLATION

2.1	PREPARING FOR THE INSTALLATION	9
2.2	INSTALLING THE FRAMING	10
2.3	ADJUSTMENT SUPPORTS	11
2.4	CONVECTION	12
2.5	POSITIONING THE SYSTEM	13
2.6	FINISHING THE WALL	14



2.1 PREPARING FOR THE INSTALLATION




NOTE

Before starting these steps, the fireplace's height and location must be established and the framing around the fireplace must be installed. The type of wall finishing that will be installed must also be chosen.

Step 1 Open the box and make sure that all the components are there and in good condition.

Step 2 Place the finishing frame in a safe location to keep from damaging it during the system's installation. Do not take it out of the box until ready to install.

1. **4x** safety bracket (maxclip)
2. **1x** bag of self-drilling screws
3. **8x** clamping collar
4. **2x** $\varnothing 6"$ duct (cold air)
5. **2x** $\varnothing 6"$ insulated duct (warm air)
6. **2x** $\varnothing 6" \times 3"$ flange
7. **2x** $\varnothing 6" \times 20"$ flange
8. **2x** grille box (cold air)
9. **2x** adjustment support
10. **1x** bag of screws
4x hex head screws to adjust
8x self-drilling screws to affix
11. **2x** air intake grille
12. **1x** linear connection box
13. **1x** installation manual
14. **1x** finishing frame






Step 3 The following page will explain how to install the framing. It is important to:

A. Make sure that the entire framing added around the linear grille consists of non-combustible steel studs and tracks. The one shown is $3 \frac{5}{8}" \times 1 \frac{1}{4}"$.

B. Calculate the desired height for the opening of the linear grille's frame in relation to the distance from the steel track it will be supported by.

C. Affix all components **to the front and back** of the studs and tracks for greater resistance.



2.2 INSTALLING THE FRAMING



Step 4 Affix a steel track to the top of the wall structure and on top of the fireplace.









Step 5 Install two vertical metal studs on each side. Affix them to the wall structure and to the steel tracks, at the top and bottom, back and front.

Step 6 Install a track that will be used to hold the linear grille at the desired height. **This track will determine the frame's height.** Affix one side to the metal stud.



NOTE

The height of this track must be **3"** above the desired location of the linear grille's contour.



2.3 ADJUSTMENT SUPPORTS




Step 10 Place the system on a flat surface. Note that the following steps must be carried out on both the right and left side.


Step 11 Use the four M5 screws and an 8 mm socket to position the adjustment supports. **Screw in slightly.**

Step 12 Calculate the thickness of the wall finishing in relation to the stud, including the cement board and finish.


10



11



12




Step 13 Adjust the supports according to the dimension calculated in the previous step, using the engraved dimensions and side of the support (see green part in circle).


Step 14 Fully tighten the hex head screws for more stability during the installation. The dimension can be readjusted as needed before installing the wall panel.

Step 15 Turn the system so that it rests on the support.


13



14



15



2.4 CONVECTION




Step 16 If the linear grille is **less than 36"** from the top of the fireplace's insulated shell, stretch the insulated duct and separate into two equal parts. Otherwise, use the two ducts.


Step 17 Connect the insulated ducts to the two flanges on the connection box and secure them with a clamping collar each. The clamping collars must be installed directly on the aluminum pipe and then covered with insulating wool.

Step 18 Hang the system on the support track using the two adjustment supports.


16



17



18




Step 19 Centre the grille in relation to the fireplace's hearth.


Step 20 With the self-drilling screws provided, temporarily screw a single hole into the horizontal track on the top of each adjustment support.

Step 21 Check that the connection box's contour is level. If not, adjust the track on which it rests.


19



20



21






2.5 POSITIONING THE SYSTEM



Step 22 Connect the other end of the insulated ducts to the fireplace's flanges. The clamping collars must be installed directly on the aluminum pipe and then covered with insulating wool.

Step 23 Test with a scrap of cement board and a piece of wall finishing (if possible). **The wall finishing must be level with the contour.** If the wall finishing is not available, confirm the thickness with a measuring tape.




Step 24 If the depth is not exact, readjust with the hex head screws on either side, using a ratchet wrench.



Step 25 After making this adjustment, check the level, positioning and depth of the connection box again.

Step 26 Screw the self-driving screws into the other screw holes in the adjustment supports.

Step 27 Install the bottom grilles as indicated in the Stûv 21 installation manual or install the convection air intake built into a wall according to the recommendations (see page 6).



2.6 FINISHING THE WALL



Step 28 Install one or more steel tracks between the fireplace and the linear grille to help affix the cement board and wall finishing. **These must be non-combustible.**

Step 29 Install studs under this track.

Step 30 Plan all the openings: linear grille, fireplace hearth, air intake (either the built-in convection or two rectangular grilles). Cut the holes out of a single cement board and drywall panel (do not use several pieces), according to the actual dimensions.




NOTE

Do not screw the cement board into the fireplace or into the linear grille. Use the framework, the insulated shell or finishing trims to affix the finishing materials.



Step 31 Attach the panel to the framework using wood screws (not included).

Step 32 Finish with plaster or other, **non-combustible** wall finishing.


Step 33 Carefully unpack the finishing frame and slide it into the contour.




28




29




30



31



32



33